
ESERCIZIO W2D4


Utilizzando Packet Tracer, lo scopo dell'esercizio è quello di configurare i tre servizi studiati a lezione: DHCP, DNS, HHTP.


Obiettivi

1- Configurare almeno 2 client per fargli ricevere degli IP da DHCP server.




Configurazione DHCP server






Switch DHCP per i due laptop



2- Configurare un <<record A>> sul server DNS, in modo da associare il nome <<epicode.internal>> all'IP del server HTTP.



O DHCP		Static
IPv4 Address	Configurazione	192.168.1.2
Subnet Mask	DHCP server	255.255.255.0
Default Gateway		0.0.0.0
DNS Server		192.168.1.100
IPv6 Configuration		

3- Fare ipconfig dai due client

```
FastEthernet0 Connection: (default port)
  Connection-specific DNS Suffix..:
  Physical Address...... 00E0.F9A1.BE15
  Link-local IPv6 Address.....: FE80::2E0:F9FF:FEA1:BE15
  IPv6 Address....: ::
  IPv4 Address..... 192.168.1.3
                                                    ipconfig /all
  Subnet Mask..... 255.255.255.0
  Default Gateway....:::
                                                     Laptop0
                              0.0.0.0
                             192.168.1.2
  DHCP Servers....:
  DHCPv6 IAID....:
  DHCPv6 Client DUID...... 00-01-00-01-53-2A-96-AA-00-E0-F9-A1-BE-15
                              192.168.1.100
Bluetooth Connection:
  Connection-specific DNS Suffix..:
  Physical Address..... 000C.CF4C.2A7B
  Link-local IPv6 Address....::
```

```
FastEthernet0 Connection:(default port)
  Connection-specific DNS Suffix..:
  Physical Address...... 0090.0CD4.624C
  Link-local IPv6 Address..... FE80::290:CFF:FED4:624C
  IPv6 Address....::::
  IPv4 Address..... 192.168.1.1
  Subnet Mask..... 255.255.255.0
  Default Gateway....:::
                             0.0.0.0
  DHCP Servers..... 192.168.1.2
  DHCPv6 IAID....:
  DHCPv6 Client DUID..........: 00-01-00-01-98-36-03-C1-00-90-0C-D4-62-4C
  DNS Servers....:::
                             192.168.1.100
Bluetooth Connection:
                                              ipconfig /all Laptop1
  Connection-specific DNS Suffix..:
  Physical Address...... 0001.64AE.C8B1
  Link-local IPv6 Address....::
  More--
```

4- Fare un test per controllare se il DNS risolve correttamente il dominio epicode.internal

